

AIR Anschluss-Set für 50 mm Abwasserschlauch (u.a. Nidek, Briot, WEKO)

Art. 000.297

Den Abwasserschlauch (2) fest auf den oberen Stutzen (4) schieben und mit einer Schlauchschelle (3) sichern. Den Luftschlauch (1) aufschieben.

Montage „im Schlauch“

Den unteren Abwasserschlauch (2) ebenfalls fest aufschieben und sichern. Beide Abwasserverbindungen auf Dichtheit prüfen !

Anschluss an Abwasserinstallation

Abzweig (5) kann wahlweise direkt in vorhandene DN50 Anschlüsse (6) oder die Anschlussverschraubung (7) eingesteckt werden.

Ggf. Reduktion für Rohre DN70 oder DN100 verwenden

Connection to the 50 mm drainage tube (e.g. Nidek, Briot, WEKO)

Art. 000.297

The drainage tube (2) is pushed onto the upper connecting piece (4) and secured with a hose clamp (3). Push the tube (1) onto it.

Assembly „inside of the tube“

The lower drainage tube (2) is pushed on as well and secured. Check both drainage connections on thickness!

Connection to the drainage fitting

Junction (5) can directly be pushed optionally into existing DN50 connections (6) or the screw connection (7).

Reductions for the pipes DN70 or DN100 can be used if necessary.

