



AIR Anschlussset DN70 für 50/ 60/ 63/75 mm Abwasserschlauch (z.B. Nidek, Briot, HUVITZ, Schöne/INDO, Topcon)

Set air.000.802

Wahlweise Dichtring (3) in den Abzweig (4) einsetzen und
Abwasserschlauch 63 mm/60 mm (2) unter Drehung einschieben
oder
O-Ring (10) über den Abwasserschlauch 50 mm (9) ziehen und
beide Teile einführen.

Dann optional den Abzweig (4) in den DN75 Abwasserschlauch (8)
einstecken
oder
die beiden Fittings (5/6) wie gezeichnet mit dem Deckel des
Wasserkastens verschrauben.

Unten ein Stück des Abwasserschlauches (7) aufschieben, das bis in
das Wasser reicht.

Oben den Abzweig (4) einschieben.
Den Luftschlauch (1) auf den Stutzen aufschieben.

Connection DN70 to 50/60/63/75 mm drainage tube (e.g. Nidek, Briot, HUVITZ, Schöne/INDO, Topcon)

Set air.000.802

Optionally push the seal ring (3) into the junction (4) and push the
drainage tube 63 mm/60 mm (2) in screwingly
or
shove the O-Ring (10) over the drainage tube 50 mm (9) and push
both parts in.

The junction (4) is then pushed alternatively into the DN75 drainage
tube (8)
or
both fittings (5/6) are screwed together with the top of the water box
as shown in the drawing.

Below a piece of the drainage tube (7) is pushed up until it reaches
the water.

On top the junction (4) is pushed in.
The tube (1) is pushed up onto the connecting piece.

